



USER GUIDE

CM52 Integrators' Manual

Reference: **WI_DEV_CM52_UGD_001**


Version: **001**

Date: **June 20, 2007**



wavecom 
Make it wireless

Trademarks

®, WAVECOM®, WISMO®, Open AT®, Wireless CPU®, Wireless Microprocessor® and certain other trademarks and logos appearing on this document, are filed or registered trademarks of Wavecom S.A. in France or in other countries. All other company and/or product names mentioned may be filed or registered trademarks of their respective owners.

Copyright

This manual is copyrighted by WAVECOM with all rights reserved. No part of this manual may be reproduced in any form without the prior written permission of WAVECOM.

No patent liability is assumed with respect to the use of the information contained herein.

No Warranty

This document is provided “as is” without any warranty of any kind. WAVECOM makes no warranties of any kind, either express or implied, including any implied warranties of merchantability, fitness for a particular purpose or noninfringement.

Table of Contents

| | | |
|---------|---|----|
| 1 | Introduction to the Integrator's Manual | 9 |
| 1.1 | OVERVIEW | 9 |
| 1.2 | HOW TO READ THE MANUAL | 9 |
| 1.3 | SERVICE AND SUPPORT | 9 |
| 1.3.1 | WEB PAGES | 9 |
| 1.4 | RELATED DOCUMENTS | 10 |
| 1.5 | ABBREVIATIONS..... | 10 |
| 2 | Integrating the CM52 Wireless CPU® | 11 |
| 2.1 | OVERVIEW | 11 |
| 2.2 | MECHANICAL DESCRIPTION | 11 |
| 2.2.1 | MECHANICAL DIMENSIONS | 11 |
| 2.2.2 | HEAT-SINK REQUIREMENTS | 16 |
| 2.2.3 | MOUNTING HOLES | 16 |
| 2.2.3.1 | MOUNTING CONFIGURATION A | 16 |
| 2.2.3.2 | MOUNTING CONFIGURATION B..... | 17 |
| 2.2.4 | RF CONNECTOR MOUNTING CONSIDERATIONS | 17 |
| 2.3 | SYSTEM CONNECTOR INTERFACE..... | 18 |
| 2.3.1 | MECHANICAL OVERVIEW..... | 18 |
| 2.3.2 | SYSTEM CONNECTOR INTERFACE PINOUT | 19 |
| 2.3.3 | LOGIC LEVELS | 21 |
| 2.3.3.1 | LEAKAGE CURRENT FOR CMOS SIGNALS | 21 |
| 2.3.3.2 | VALIDITY OF CMOS SIGNALS | 21 |
| 2.4 | POWER SUPPLY | 21 |
| 2.4.1 | POWER SUPPLY INPUT CAPACITANCE | 22 |
| 2.4.2 | POWER SUPPLY AND GROUND SIGNALS | 23 |
| 2.4.2.1 | POWER SUPPLY SIGNAL PINS | 23 |
| 2.4.2.2 | GROUND SIGNAL PINS | 23 |

| | | |
|---------|--|----|
| 2.4.3 | POWER CONSUMPTION | 23 |
| 2.4.3.1 | VCC_MAIN SUPPLY POWER CONSUMPTION..... | 24 |
| 2.4.3.2 | VCC_AUX SUPPLY POWER CONSUMPTION..... | 24 |
| 2.4.3.3 | POWER DOWN MODE (MINIMUM DC POWER CONSUMPTION) | 25 |
| 2.4.4 | VREF SIGNAL DETAILS | 25 |
| 2.5 | REAL TIME CLOCK (RTC) CIRCUIT..... | 26 |
| 2.5.1 | RTC INITIALIZATION..... | 26 |
| 2.5.2 | RTC FUNCTIONAL BLOCK DIAGRAM..... | 26 |
| 2.6 | AUDIO INTERFACE..... | 27 |
| 2.6.1 | DIGITAL AUDIO | 28 |
| 2.6.1.1 | DATA FORMAT | 28 |
| 2.6.1.2 | TIMING | 29 |
| 2.6.2 | ANALOG AUDIO | 30 |
| 2.7 | SERIAL DATA INTERFACE | 33 |
| 2.8 | ANTENNA INTERFACE | 33 |
| 2.8.1 | ANTENNA CONNECTOR..... | 34 |
| 2.8.2 | RF OUTPUT POWER..... | 35 |
| 2.8.3 | CARRIER APPROVAL | 36 |
| 2.8.4 | ANTENNA DIAGNOSTICS | 36 |
| 3 | Recommended Interface Circuitry..... | 38 |
| 3.1 | STATUS GROUP RECOMMENDED CIRCUITRY | 38 |
| 3.1.1 | MODULE_PWR_EN_B | 39 |
| 3.1.2 | VREF | 39 |
| 3.1.3 | RI | 40 |
| 3.1.4 | HW_SD..... | 40 |
| 3.2 | DATA GROUP RECOMMENDED CIRCUITRY | 42 |
| 3.2.1 | VPPFLASH/DCD..... | 42 |
| 3.3 | PCM GROUP RECOMMENDED CIRCUITRY | 43 |
| 3.4 | ANALOG AUDIO GROUP RECOMMENDED CIRCUITRY | 44 |
| 3.4.1 | CREATING AN ANALOG GROUND..... | 44 |
| 3.4.2 | ANALOG GROUND VS. AGND | 45 |
| 3.4.3 | MICROPHONE PATH | 45 |

| | | |
|-------|---|----|
| 3.4.4 | LOUDSPEAKER PATH | 46 |
| 3.5 | SYSTEM CONNECTOR IO FUNCTIONALITY | 47 |
| 4 | Functional Description | 49 |
| 5 | Hints for Integrating the Wireless CPU® | 50 |
| 5.1 | PRECAUTIONS | 50 |
| 5.2 | WHERE TO INSTALL THE WIRELESS CPU® | 50 |
| 5.3 | SAFETY STANDARDS..... | 50 |
| 5.4 | ANTENNA..... | 51 |
| 5.4.1 | ANTENNA TYPE | 51 |
| 5.4.2 | ANTENNA PLACEMENT | 51 |
| 5.5 | POSSIBLE COMMUNICATION DISTURBANCES | 51 |
| 6 | Technical Data | 52 |

List of Tables

| | |
|--|----|
| TABLE 1: ABBREVIATION DEFINITIONS | 10 |
| TABLE 2: SYSTEM CONNECTOR AND MATING PART NUMBERS | 18 |
| TABLE 3: PIN-OUT OF THE SYSTEM CONNECTOR HEADER | 20 |
| TABLE 4: CMOS OUTPUT / INPUT ELECTRICAL CHARACTERISTICS | 21 |
| TABLE 5: MAXIMUM LEAKAGE CURRENT FOR CMOS SIGNALS | 21 |
| TABLE 6: CM52 POWER SUPPLY REQUIREMENTS | 22 |
| TABLE 7: POWER SUPPLY INPUT CAPACITANCE (0.6W VARIANTS) | 22 |
| TABLE 8: POWER SUPPLY INPUT CAPACITANCE (3W VARIANTS) | 22 |
| TABLE 9: CM52 POWER SUPPLY SIGNALS | 23 |
| TABLE 10: CM52 GROUND SIGNALS | 23 |
| TABLE 11: VCC_MAIN SUPPLY POWER CONSUMPTION | 24 |
| TABLE 12: VCC_AUX SUPPLY POWER CONSUMPTION | 25 |
| TABLE 13: MODULE_PWR_EN_B SIGNAL PARAMETERS | 25 |
| TABLE 14: VREF SUPPLY DETAILS | 26 |
| TABLE 15: FREQUENCY CHARACTERISTICS OF THE RTC | 26 |
| TABLE 16: CM52 AUDIO SIGNALS | 27 |
| TABLE 17: CM52 DIGITAL AUDIO SIGNALS | 28 |
| TABLE 18: PCM TIMING PARAMETERS | 29 |
| TABLE 19: CM52 ANALOG AUDIO SIGNALS | 30 |
| TABLE 20: AUDIO CHARACTERISTICS | 30 |
| TABLE 21: SERIAL DATA CHANNELS | 33 |
| TABLE 22: ANTENNA CONNECTOR SUPPLIERS | 35 |
| TABLE 23: MOBILE STATION NOMINAL ANALOG POWER LEVELS | 36 |
| TABLE 24: MOBILE STATION CDMA MAXIMUM OUTPUT POWER | 36 |
| TABLE 25: RANGE OF ADC READINGS FOR AN EXTERNAL ANTENNA | 37 |
| TABLE 26: PIN DIRECTION FOR GENERAL PURPOSE SIGNALS | 48 |
| TABLE 27: TECHNICAL DATA | 53 |

List of Figures

| | |
|---|----|
| FIGURE 1: CM52 PRIMARY SIDE | 11 |
| FIGURE 2: CM52 SECONDARY SIDE | 11 |
| FIGURE 3: MECHANICAL DIMENSIONS DRAWING (CM52003 VARIANT) | 12 |
| FIGURE 4: MECHANICAL DIMENSIONS DRAWING (CM52001 AND CM52004 VARIANTS) | 13 |
| FIGURE 5: MECHANICAL DIMENSIONS DRAWING (CM52002 VARIANT) | 14 |
| FIGURE 6: KEEP-OUT DRAWING OF CM52 | 15 |
| FIGURE 7: MOUNTING CONFIGURATION A | 16 |
| FIGURE 8: MOUNTING CONFIGURATION B | 17 |
| FIGURE 9: APPLICATION HOUSING | 17 |
| FIGURE 10: 40-PIN SYSTEM CONNECTOR | 18 |
| FIGURE 11: 40-PIN SYSTEM CONNECTOR PIN NUMBERING | 18 |
| FIGURE 12: RTC FUNCTIONAL BLOCK DIAGRAM | 27 |
| FIGURE 13: PCM TIMING DIAGRAM | 29 |
| FIGURE 14: BIAS DIAGRAM EXAMPLE | 31 |
| FIGURE 15: MICROPHONE IMPLEMENTATION EXAMPLE | 32 |
| FIGURE 16: DIFFERENTIAL IMPLEMENTATION EXAMPLE | 32 |
| FIGURE 17: COLOR AND KEYING FOR VARIOUS FAKRA CONNECTORS | 34 |
| FIGURE 18: SAMPLE SMA CONNECTOR AND MOUNTING HOLE | 35 |
| FIGURE 19: ANTENNA DIAGNOSTIC CIRCUIT | 37 |
| FIGURE 20: STATUS GROUP DIAGRAM | 39 |
| FIGURE 21: PIN 15 HW_SD DIAGRAM | 40 |
| FIGURE 22: SHUT DOWN SEQUENCE TIMELINE | 41 |
| FIGURE 23: DATA GROUP DIAGRAM | 42 |
| FIGURE 24: PCM GROUP DIAGRAM | 43 |
| FIGURE 25: CREATING AN ANALOG REFERENCE VOLTAGE (BIAS) | 44 |
| FIGURE 26: BIAS/VANA REFERENCE | 44 |
| FIGURE 27: MICROPHONE IMPLEMENTATION EXAMPLE | 45 |
| FIGURE 28: LOUDSPEAKER IMPLEMENTATION EXAMPLE | 46 |

Revision History

| Release | Date | Summary of Changes |
|---------|------------|---|
| PA1 | 05/07/2004 | Initial Draft |
| PA2 | 09/01/2004 | Formatting |
| PA3 | 11/17/2004 | Updated Chapters 1 & 2 |
| PA4 | 11/29/2004 | Updated with review feedback |
| PA5 | 12/01/2004 | Updated the List of Tables and Figures |
| PA6 | 06/16/2005 | Current Consumption Table, RTC Block Diagram, Mechanical Drawing |
| A | 09/15/2005 | Release version |
| PB1 | 11/30/2005 | Updates for VREF sourcing capability, inrush current, mechanical mounting, recommended application circuitry and CMOS leakage current. |
| PB2 | 02/16/2006 | Update to Power consumption section & Formatting updates |
| PB3 | 03/08/2006 | Updated mechanical drawings, Re-formatted Table 2, Added RTC Frequency Characteristics. |
| PB4 | 03/16/2006 | Updated Sections: 2.5 - Real Time Clock Circuit, 2.8.2 – RF Output Power. Added section 3.1.3 – RI |
| PB5 | 03/22/2006 | Updated Table of Contents. Updated Sections: 3.1.3 – RI and 3.1.4 – HW_SD. Removed the Random Stationary Vibration information from Section 6 – Technical Data. |
| B | 03/24/2006 | Release Version |
| PC1 | 06/02/2006 | Updated Vibration Specification and add Minimum Off-Time |
| PC2 | 06/13/2006 | Added RTC Initialization section and reformatted Technical Data table |
| 001 | 06/20/2007 | Update product references, Wavecom format |

1 Introduction to the Integrator's Manual

1.1 Overview

This manual is for use as a guide to the setup, installation, and use of the CM52 Wireless CPU® into your application. The Wireless CPU® may be tested using the developer's board, which is supplied together with all the necessary tools in the Developer's Kit.

1.2 How to Read the Manual

This manual is divided into six chapters:

Chapter 1 gives a general view of the integrator's manual. A list of related documents as well as a list of abbreviations used throughout the manual is also included. Information concerning service and support is also presented.

Chapter 2 focuses on helping the hardware developer to integrate the CM52 hardware into their application. An overview of the mechanical and electrical information is provided. Interface specifications, RF output power, and power supply issues are included in this chapter.

Chapter 3 contains information on recommended circuitry needed to ensure proper performance from the CM52 Wireless CPU®.

Chapter 4 describes several of the common cellular functions available with the CM52.

Chapter 5 provides some hints for integrating the Wireless CPU®.

Chapter 6 provides a summary of the technical data for the CM52 Wireless CPU®.

1.3 Service and Support

1.3.1 Web Pages

Visit our Web site for more information about where you can buy our products or for recommendations for accessories and components. The address is:

<http://www.wavecom.com>

To register for product news and announcements or for product questions, work with your usual Wavecom contact.

1.4 Related Documents

CM52 AT Command Manual – Details the AT command interface for the CM52

The CM52 is based upon the following mobile standards:

- **IS-2000 Release 0 (1XRTT), MOB_P_REV** – CDMA protocol
- **TIA/EIA/IS-91** – *Mobile Station – Base Station Compatibility Standard for 800 MHz Analog Cellular*
- **TIA/EIA-98-D** – *Recommended Minimum Performance Standards for Dual-Mode Spread Spectrum Mobile Stations*

1.5 Abbreviations

| Abbreviation | Definition |
|--------------|----------------------------------|
| AGND | Analog Reference |
| AMPS | Advanced Mobile Phone System |
| AT | Attention Command |
| CDMA | Code Division Multiple Access |
| CTS | Clear to Send |
| DCD | Data Carrier Detect |
| DFMS | Data from Mobile Station |
| DTMS | Data to Mobile Station |
| DTR | Data Terminal Ready |
| EMI | Electromagnetic Interference |
| ESD | Electrostatic Discharge |
| GND | Chassis GrouND |
| IRA | International Reference Alphabet |
| LSB | Least Significant Bit |
| ME | Mobile Equipment |
| MO | Mobile Originated |
| MS | Mobile Station |
| MT | Mobile Terminated |
| OEM | Original Equipment Manufacturer |
| PCB | Printed Circuit Board |
| PCM | Pulse Code Modulation |
| PIN | Personal Identification Number |
| PSD | Power Spectral Density |
| RD | Receive Data, also known as DFMS |
| RF | Radio Frequency |
| RI | Ring Indicator |
| RTS | Request to Send |
| SMS | Short Message Service |
| TD | Transmit Data, also know as DTMS |

Table 1: Abbreviation Definitions

2 Integrating the CM52 Wireless CPU®

2.1 Overview

The CM52 is a dual band, dual mode CDMA transceiver Wireless CPU®. It operates in the 800 MHz band for CDMA and AMPS and in the 1900 MHz band for CDMA. It is designed for consumer and OEM industrial voice and data applications.

The CM52 Wireless CPU® is intended for mounting into an application developer's chassis to provide wireless communication capability for the product. The target chassis could be in a wide variety of forms such as a residential electric meter, a point of sale terminal, an alarm panel, or an automobile console. All initial configuration, mode control, and operational commands are issued to the Wireless CPU® over an RS-232 serial port using a flexible AT command format. The Wireless CPU® circuitry has been designed to meet the environmental requirements of a large range of commercial and industrial users.

2.2 Mechanical Description

The CM52 has no mechanical elements other than the main PCB assembly. All critical electronic components are shielded using six cans to prevent internal and external electromagnetic interference from degrading the Wireless CPU performance and to prevent the Wireless CPU® from interfering with other nearby devices. The Wireless CPU® is plugged into the fixed mating connector and secured with four screws.

The antenna interface is provided via a board mounted RF connector at the opposite end of the board from the system connector. See Section 2.8 for more information on antenna connector options.

The Wireless CPU® has no keypad, display, microphone, speaker, or battery. The following figures show 3-D models of the Wireless CPU®.




Figure 1: CM52 Primary Side




Figure 2: CM52 Secondary Side

2.2.1 Mechanical Dimensions

The following figures provide the mechanical dimensions for several CM52 variants (CM52002, CM52003, and CM52004). There is also a drawing detailing the mechanical keep-out regions.




Figure 3: Mechanical Dimensions Drawing (CM52003 variant)




Figure 4: Mechanical Dimensions Drawing (CM52001 and CM52004 variants)




Figure 5: Mechanical Dimensions Drawing (CM52002 variant)




Figure 6: Keep-out drawing of CM52

2.2.2 Heat-Sink Requirements

The application is required to provide a heat-sink for the 3W AMPS capabilities of the CM52. The application should be designed to provide a heat sink with a thermal resistance of 4.0 °C/W. For applications that disable the 3W mode (Class I) and only operate in 0.6W mode (Class III) a heat-sink is not required.

2.2.3 Mounting Holes

Mounting holes and tabs are provided for proper mechanical support of the CM52 Wireless CPU® in the customer's application. The OEM's application must provide sufficient mechanical retention using the mounting holes and/or tabs or some other means. The system connector and RF connector connections should not be used as a means of mechanical support. Also, please note that the mounting holes may not substitute for the actual grounding pins provided via the system connector.

Two mounting configurations are supported (A and B). Each has its own mechanical vibration specification. Section 6 details the mechanical vibration specification for both configurations. For machine screw mounting a wet torque of 8 in-lbs is recommended.

2.2.3.1 Mounting Configuration A

Mounting configuration "A" uses four exterior mounting holes that support #4 size screws.




Figure 7: Mounting Configuration A

2.2.3.2 Mounting Configuration B

Mounting configuration "B" uses four 3/4 mounting holes that support #6 size screws.




Figure 8: Mounting Configuration B

Note: This is the recommend mounting configuration due to the higher mechanical vibration specification supported.

2.2.4 RF Connector Mounting Considerations

When designing the application the designer should ensure that the housing does not degrade the RF performance of the CM52. A minimum clearance of 4mm from the surface of the PCB to the housing on the back side of the RF connectors should be provided.





Figure 9: Application Housing

2.3 System Connector Interface

2.3.1 Mechanical Overview

External interfaces to the Wireless CPU® are made primarily through a 40 pin, standard 0.050-inch pitch, ODU header show below.



Features

- Vacuum adapter plate
- SMT version
- pin cross-section 0.38 x 0.38 mm
- 10-20-30-40-50 positions available
- without guide pins

Figure 10: 40-Pin System Connector




Figure 11: 40-Pin System Connector Pin Numbering

| Description | ODU Part Number | Dimension A | Dimension B |
|-------------------------|---------------------|-------------|-------------|
| System Connector | 515.569.035.140.xxx | 24.13 mm | 22.86 mm |
| Mating Ribbon Connector | 525.060.035.040.xxx | | |
| SMT Mating Header | 525.041.035.040.xxx | | |
| Ribbon cable, AWG 30 | 921.659.031.040.000 | | |

Table 2: System Connector and Mating Part Numbers

Please consult the ODU site for more information on mating options: <http://www.odu.de>

2.3.2 System Connector Interface Pinout

| Pin | Signal | Description | Dir | Pin Type | Alternate Function | Dir | Pin Type |
|-----|-----------------|---|-------|--------------|-----------------------|-----|----------|
| 1 | Reserved | | | | TIMEMARK ¹ | O | CMOS |
| 2 | VREF | Logic Voltage | O | Reference | | | |
| 3 | Reserved | | | | GPS Fix ¹ | O | CMOS |
| 4 | VRTC | Supply pin for RTC ² | I | Power | GPS VRTC ¹ | I | Supply |
| 5 | GND | Chassis Ground | | Ground | | | |
| 6 | GND | Chassis Ground | | Ground | | | |
| 7 | AFMS | Analog Audio from Wireless CPU® | O | Audio | | | |
| 8 | GND | Chassis Ground | | Ground | | | |
| 9 | AGND | Analog Reference | | Audio | | | |
| 10 | ATMS | Analog Audio to Wireless CPU® | I | Audio | | | |
| 11 | Reserved | | | | UART3_RX ¹ | I | CMOS |
| 12 | MODULE_PWR_EN_B | Switches the Wireless CPU® on/off (hardware-wise), active low | I | | | | |
| 13 | Reserved | | | | UART3_TX ¹ | O | CMOS |
| 14 | Reserved | | | | | | |
| 15 | HW_SD | Hardware shutdown | I/O | | | | |
| 16 | Reserved | | | | | | |
| 17 | PCMCLK | PCM Clock output | O | CMOS | | | |
| 18 | PCMSYNC | PCM Frame sync | O | CMOS | | | |
| 19 | PCMULD | PCM Voice input to Wireless CPU® | I | CMOS | | | |
| 20 | PCMDLD | PCM Voice output from Wireless CPU® | O | CMOS | | | |
| 21 | GND | Chassis Ground | | Ground | | | |
| 22 | GND | Chassis Ground | | Ground | | | |
| 23 | DCD / VPPFLASH | Data Carrier Detect & Flash programming voltage input | O / I | CMOS / Power | | | |
| 24 | Reserved | | O | | RINGER | O | CMOS |

¹ Default function if GPS option on board

² Default function if RTC option on board

| Pin | Signal | Description | Dir | Pin Type | Alternate Function | Dir | Pin Type |
|-----|-------------|-----------------------------------|-----|----------|--------------------------|-----|----------|
| 25 | CTS | Clear to send | O | CMOS | | | |
| 26 | DTR | Data Terminal Ready | I | CMOS | | | |
| 27 | TD | Transmit data, also known as DTMS | I | CMOS | | | |
| 28 | RTS | Request to Send | I | CMOS | | | |
| 29 | VCC_AUX | 13.8 VDC supply input | I | Power | | | |
| 30 | RD | Receive data, also known as DFMS | O | CMOS | | | |
| 31 | VCC_AUX | 13.8 VDC supply input | I | Power | | | |
| 32 | VCC_AUX | 13.8 VDC supply input | I | Power | | | |
| 33 | VCC_MAIN | 5 VDC regulated supply | I | Power | | | |
| 34 | VCC_MAIN | 5 VDC regulated supply | I | Power | | | |
| 35 | SDA_SPI_IN | Reserved | | CMOS | SDA_SPI_IN | IO | |
| 36 | SCL_SPI_CLK | Reserved | | CMOS | SCL_SPI_CLK | IO | |
| 37 | SYS_DTM_2 | Transmit Data for UART2 | I | CMOS | GPS TX Data ¹ | I | |
| 38 | SPI_OUT | Reserved | | CMOS | SPI_OUT | IO | |
| 39 | SYS_DFM_2 | Receive Data for UART2 | O | CMOS | GPS RX Data ¹ | O | |
| 40 | RI | Ring Indicator | O | CMOS | | | |

Table 3: Pin-out of the System Connector Header

2.3.3 Logic Levels

Many of the signals present in the interface are CMOS signals where the following levels apply. The nominal voltage level for the CMOS signals is 2.9 V. Drive capability of the outputs is also indicated.

| Parameter | Test Conditions | Limits | | Units |
|--|-----------------|--------|------|-------|
| | | Min | Max | |
| High level output voltage ($I_{OH} = 800 \mu A$) | V_{OH} | 2.45 | 3.1 | Volts |
| Low level output voltage ($I_{OL} = 800 \mu A$) | V_{OL} | 0 | 0.45 | Volts |
| High level input voltage | V_{IH} | 1.9 | 3.1 | Volts |
| Low level input voltage | V_{IL} | 0 | 0.9 | Volts |

Table 4: CMOS Output / Input Electrical Characteristics

Note: The maximum voltage that may be applied to any CMOS signal is 3.1V

2.3.3.1 Leakage Current for CMOS Signals

The following table defines the maximum leakage for the CMOS inputs of the CM52.

| Parameter | Max | Units |
|---|-----|---------|
| High level drive for input signal with internal pull down | 60 | μA |
| Low level drive for input signal with internal pull up ³ | 60 | μA |

Table 5: Maximum Leakage Current for CMOS signals

2.3.3.2 Validity of CMOS signals

The CMOS signals of the CM52 shall only be considered valid when the level of the VREF signal is above 2.3V.

2.4 Power Supply

The CM52 requires a dual DC power supply implementation in the application. VCC_MAIN provides power to the entire radio while VCC_AUX provides power for the 3-Watt functionality and biasing for the RF switches.

Note: VCC_AUX must be present if the 3W option is provided even if it is not used. If the 3W circuitry is **not** populated then VCC_AUX is not required or may be bussed together with VCC_MAIN.

³ DTR is 90 μA and HW_SD is 350 μA

The following table summarizes the power supply requirements from the application.

| Input Supply | Voltage (Volts DC) | Max. Current (Amps) | Max. Ripple (mVpp) | |
|----------------|--------------------|---------------------|--------------------|--------------|
| | | Operation | 0- 4KHz | 4 KHz- 10MHz |
| VCC_MAIN | 5.00 ± 10% | 1.4 | 100mVpp | 50mVpp |
| VCC_AUX | 13.8 ± 20% | 1.3 | 600mVpp | 240mVpp |
| VRTC(no GPS) | 1.8 to 3.9 | 1.2 uA | | |
| VRTC(with GPS) | 3.4 to 3.9 | 500 uA | | |

Table 6: CM52 Power Supply Requirements

2.4.1 Power Supply Input Capacitance

It should be noted that when applying power to the Wireless CPU®, the current will exceed the maximum input current specified in **Table 6: CM52 Power Supply Requirements**, or any other CM52 electrical specification due to the transient current required to charge the de-coupling capacitors of the Wireless CPU® (specified below as C_{IN}). The magnitude and duration of the transient current spike is solely dependent on the application power supply design. Any built-in short circuit protection in the application power supply must take this in to account as well as all other "Power Supply" specifications.

The maximum total input capacitance on VCC_MAIN is 100uF. However at "Contact", 60uF will be charged instantly by the application's power supply. Then at "Wake" an additional 14.5uF will be instantly charged. At that point internal regulators are activated and limit the charge rate of the remaining capacitance. If VCC_MAIN and VCC_AUX are tied together (0.6W variants only) then the input capacitance on VCC_AUX is negligible.

The "Wakeup" condition occurs when the MODULE_PWR_EN_B signal transitions from High to Low. The "Contact" condition occurs when voltage is first asserted to VCC_MAIN, and or VCC_AUX.

| Parameter | Contact | Wakeup | Units |
|---|---------|--------|-------|
| VCC_MAIN Input Capacitance (C_{IN}) | 60 | 14.5 | uF |
| VCC_AUX Input Capacitance (C_{IN}) | 33 | 10 | pF |

Table 7: Power Supply Input Capacitance (0.6W variants)

| Parameter | Contact | Wakeup | 3W assertion |
|---|---------|---------|--------------|
| VCC_MAIN Input Capacitance (C_{IN}) | 60 uF | 14.5 uF | n/a |
| VCC_AUX Input Capacitance (C_{IN}) | 10 uF | 10 pF | 20 uF |

Table 8: Power Supply Input Capacitance (3W variants)

2.4.2 Power Supply and Ground Signals

2.4.2.1 Power Supply Signal Pins

Following is a list of the power supply pins:

| Pin | Signal | Description |
|-----|-------------------|--|
| 4 | VRTC ⁴ | 1.8 V to 3.9V (3.4V to 3.9V if GPS mounted) |
| 29 | VCC_AUX | 13.8 volt \pm 20% |
| 31 | VCC_AUX | 13.8 volt \pm 20% |
| 32 | VCC_AUX | 13.8 volt \pm 20% |
| 33 | VCC_MAIN | 5 volt \pm 10% regulated |
| 34 | VCC_MAIN | 5 volt \pm 10% regulated |

Table 9: CM52 Power Supply Signals

For the power supply signals in the above table with multiple pins defined, the application shall bus all defined pins together.

2.4.2.2 Ground Signal Pins

The ground signal in the CM52 is Digital Ground, **GND**, connected to the system connector interface through pin numbers 5, 6, 8, 21 and 22.

Following is a list of the ground pins:

| Pin | Signal | Description |
|-----|--------|----------------|
| 5 | GND | Digital Ground |
| 6 | GND | Digital Ground |
| 8 | GND | Digital Ground |
| 21 | GND | Digital Ground |
| 22 | GND | Digital Ground |

Table 10: CM52 Ground Signals

Digital Ground (GND) is the logical reference of all digital signals in the System Interface as well as the DC return of the power supply signal, VCC_MAIN and VCC_AUX (used for AMPS Class I operation). All 5 ground pins in the Wireless CPU® need to be connected to the application ground. The PCB mounting holes may not to be used as substitute for the ground signal pins of the system connector interface.

2.4.3 Power Consumption

The following tables show typical and maximum values of current that can be expected from the Wireless CPU® in different modes of operation.

⁴ Only applicable to units with GPS or RTC functions

2.4.3.1 VCC_MAIN Supply Power Consumption

| Parameter | Min | Typical | Max | Units |
|--|-----|---------|------|-------|
| Input Voltage | 4.5 | 5 | 5.5 | V |
| In AMPS Call on Power Level 0 (Power Class I) | | 0.62 | 0.82 | A |
| In AMPS Call on Power Level 2 | | 0.94 | 1.4 | A |
| In CDMA call-Cellular Mode | | 0.77 | 1.2 | A |
| In CDMA call-PCS Mode | | 0.84 | 1.3 | A |
| CDMA burst duration for Network update | | 1.2 | | s |
| Standby/Idle Current Draw in Slotted Mode (CDMA) | | | | |
| 1.28 sec slot | | 9.6 | | mA |
| 2.56 sec slot | | 7.2 | | mA |
| 5.12 sec slot | | 4.5 | | mA |
| Stand-by/Idle mode (AMPS) | | 45 | | mA |
| Powered Down Current Draw | | 1 | 5 | uA |

Table 11: VCC_MAIN Supply Power Consumption

Notes

- The typical current measurements noted in CDMA mode are with the following settings:
 - CDMA-Cellular (800MHz): Band = IS-2000, Cell-Power = -104dBm, Channel Number 358
 - CDMA-PCS (1900MHz): Band = IS-2000, Cell-Power = -104dBm, Channel Number 563

Maximum Slot Cycle Index for both 800MHz and 1900MHz modes = 1
- Measurements are based on worst case scenario—CM52 with 3W option. Values for CM52 with no 3W option could be marginally lower.
- A +10% tolerance is allowed for the listed maximum values.

2.4.3.2 VCC_AUX Supply Power Consumption

The VCC_AUX power supply is required for CM52 variants with 3W AMPS circuitry populated. This requirement is regardless of whether the AMPS Power Class 1 is used.

The VCC_AUX power supply is not required for any CM52 Wireless CPU® other than those with 3W AMPS circuitry populated, but it can be applied if desired. In this case, the VCC_AUX pins can be supplied as 5V, 13.8V or Grounded.

| Parameter | Min | Typical | Max | Units |
|--|-----|---------|------|-------|
| Input Voltage | 11 | 13.8 | 16.6 | V |
| In a Call on Power Level 0 (Power Class I) | | 0.88 | 1.3 | A |
| In a Call on Power Level 2 | | 3.5 | 4.5 | mA |
| AMPS Burst Duration for network update | | 0.16 | | S |
| Stand-by/Idle mode (Rx ON) | | 0.5 | 1 | uA |
| Powered Down Current Draw | | 1 | | uA |

Table 12: VCC_AUX Supply Power Consumption

Note: The typical values observed are made in AMPS call with voice channel set to 358.

2.4.3.3 Power Down Mode (Minimum DC Power Consumption)

In power down mode the Wireless CPU® is placed in a low power consumption state under the control of host application. In this mode, the unit consumes approximately 1 uA of current as measured from the VCC_MAIN supply input and 1 uA of current as measured from the VCC_AUX supply input.

To activate this mode, the Module_PWR_EN_B signal on pin 12 of the system connector is pulled to a logic level 1, which puts the Wireless CPU® into the low power state. The Wireless CPU® will stay in the low power state until the Module_PWR_EN_B signal is driven low by an external open collector transistor in the application circuitry. Turning the external open collector transistor off will cause the Module_PWR_EN_B signal to float high and turn the Wireless CPU® off. The Module_PWR_EN_B line is tied to VCC_MAIN through a 100kΩ pull-up resistor so the sink current in the external open collector transistor is minimal.

| Parameter | Minimum | Nominal | Maximum | Units |
|---|---------|---------|---------|-------|
| Internal Pull-up Resistance to VCC_MAIN | 90 | 100 | | KΩ |
| Off-Time | 1 | | | S |

Table 13: Module_Pwr_EN_B Signal Parameters

In the Power Down Mode the radio is inactive and serial communication with the CM52 is suspended.

2.4.4 VREF Signal Details

The following table defines the current sourcing capabilities and behavior of the VREF signal. This signal is defined as a logic reference voltage, not a supply voltage to the application. Refer to **3 Recommend Circuitry** for interface circuit implementation suggestions.

| Parameter | Minimum | Typical | Maximum | Units |
|--------------------------|---------|---------|---------|-------|
| Supply Voltage Reference | 2.45 | 2.9 | 3.1 | V |
| Output Current | | | 1000 | uA |
| Application Load | 10 | 100 | | KΩ |
| Rise Time | | | 3300 | us |
| Fall Time | | | 0.8 | ms |

Table 14: VREF Supply Details

2.5 Real Time Clock (RTC) Circuit

The real time clock is a feature provided by the CM52 that allows the Wireless CPU® to sleep and wakeup for a definable number of cycles, as configured by the host application. This feature is an optional hardware feature. Please refer to the CM52 Software User's Guide and AT Command Manual for more details about usage scenarios and programming this feature.

The following table defines the Frequency Characteristics of the RTC:

| Item | Symbol | Condition | Rating | Unit |
|---|----------------|--|-------------|---------------------------|
| Frequency precision | $\Delta f / f$ | Ta = +25 °C, VDD = 3.0 V | 5 ± 23 (*1) | X 10 ⁻⁶ |
| Frequency / voltage characteristics | f / V | Ta = +25 °C, VDD = 2.0 V to 5.0 V | ± 2 Max. | X 10 ⁻⁶ / V |
| Frequency / temperature characteristics | Top | Ta = -20 °C to +70 °C, VDD = 3.0 V; +25 °C reference | +10 / -120 | X 10 ⁻⁶ |
| Aging | fa | Ta = +25 °C, VDD = 3.0V, first year | ± 5 Max. | X 10 ⁻⁶ / year |

Table 15: Frequency characteristics of the RTC

(*1) precision gap per month: 1 minutes (excluding offset value)

2.5.1 RTC Initialization

When power is first applied to the RTC via the VRTC pin of the system connector it is necessary to allow the CM52 to initialize the RTC. In order to initialize the RTC the CM52 must be powered up while power is applied to the RTC. Once the Restart message is received the CM52 can be shutdown via the normal procedures. If the supply to the VRTC input is interrupted then the CM52 must be allowed to power up to initialize the RTC again.

2.5.2 RTC Functional Block Diagram

The purpose of this section is to provide an overview of the Real Time Clock feature functional block and interconnects that are shared with the application.




Figure 12: RTC Functional Block Diagram

2.6 Audio Interface

The audio-related signals are: the analog audio signals

- **ATMS** (Audio to Mobile Station),
- **AFMS** (Audio from Mobile Station),
- **PCM** (Pulse Code Modulation) signals (**PCMULTD**, **PCMDLD**, **PCMCLK**, and **PCMSYNC**).

| Pin | Signal | Description |
|-----|---------|---|
| 7 | AFMS | Audio Output From Wireless CPU®. |
| 10 | ATMS | Audio Input to Wireless CPU®. |
| 9 | AGND | Analog Reference |
| 17 | PCMCLK | PCM Clock Output from Wireless CPU®. |
| 18 | PCMSYNC | PCM Frame Sync Output from Wireless CPU®. |
| 19 | PCMULTD | PCM Voice Input to Wireless CPU®. |
| 20 | PCMDLD | PCM Voice Output from Wireless CPU®. |

Table 16: CM52 Audio Signals

2.6.1 Digital Audio

The CM52 provides digital audio capability over the system connector. The digital audio signals enable the connection of a digital audio source. The receiver is bypassing the analog audio processing functions performed within the Wireless CPU®. The digital audio interface includes the following PCM signals:

| Pin | Signal | Description |
|-----|---------|--------------------------------------|
| 17 | PCMCLK | PCM Clock Output from Wireless CPU®. |
| 18 | PCMSYNC | PCM Frame Sync from Wireless CPU®. |
| 19 | PCMULTD | PCM Voice Input to Wireless CPU®. |
| 20 | PCMDLD | PCM Voice Output from Wireless CPU®. |

Table 17: CM52 Digital Audio Signals

Already defined CMOS output/input electrical characteristics apply (see Section 1.1.1). The PCM signals are referenced to digital ground.

The PCM format (for **PCMULTD** and **PCMDLD**) follows a linear PCM data format with 13-bit data embedded in a 16-bit word. The data bits in **PCMULTD** (input) and **PCMDLD** (output) are aligned so that the MSB in each word occurs on the same clock edge. See timing diagram in 2.6.1.2.

2.6.1.1 Data Format

The CM52 Wireless CPU® implements a 13-bit linear PCM with the 13-bit data embedded in a 16-bit word as follows.

Each PCM word shall contain 16-bits D15 – D00. D15 – D03 is the 2's-complement value of the 13-bit PCM, with D15 as the sign bit. D15 is the MSB while D03 is the LSB. Note that the MSB is sent in first place. Ensure that the read data from PCMDLD is right shifted three times and sign extended before being used

| 13-bit linear | | | | | | | | | | | | | | | |
|---------------|----|----|----|----|----|---|---|---|---|---|---|-----|---|---|---|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| MSB | | | | | | | | | | | | LSB | X | X | X |

| Bit | Contents |
|-----------|-----------------------------------|
| D15 – D03 | 2's complement of the 13-bit PCM. |
| D02 – D00 | Bits are undefined. |

2.6.1.2 Timing

Timing shall be according to the following diagram (see **Figure 13: PCM Timing Diagram**). The signals in the diagram shall be interpreted according to the following relation.




Figure 13: PCM Timing Diagram

The meaning and value of the timing parameters are described in **Table 18**.

| Name | Description | Min | Typical | Max | Unit |
|-----------------------|---|------|---------|-----|------|
| t_{SYNC} | PCM_SYNC cycle time. | | 125 | | Us |
| | PCM_SYNC frequency | | 8.0 | | kHz |
| t_{SYNCA} | PCM_SYNC asserted time. | 62.4 | 62.5 | | Us |
| t_{SYNCD} | PCM_SYNC de-asserted time. | 62.4 | 62.5 | | Us |
| $t_{\text{SU(SYNC)}}$ | PCM_SYNC setup time to PCM_CLK rising. | 1.95 | | | us |
| $t_{\text{H(SYNC)}}$ | PCM_SYNC hold time after PCM_CLK falling. | 1.95 | | | us |
| t_{CLK} | PCM_CLK cycle time. | | 7.8 | | us |
| | PCM_CLK frequency | | 128 | | kHz |
| t_{CLKH} | PCM_CLK high time. | 3.8 | 3.9 | | us |
| t_{CLKL} | PCM_CLK low time. | 3.8 | 3.9 | | us |
| t_{PDL} | Propagation delay from PCM_CLK rising to PCM_DLD valid. | | | 50 | ns |
| $T_{\text{SU(ULD)}}$ | PCM_ULD setup time to PCM_CLK falling. | 70 | | | ns |
| $T_{\text{H(ULD)}}$ | PCM_ULD hold time after PCM_CLK falling. | 20 | | | ns |

Table 18: PCM Timing Parameters

2.6.2 Analog Audio

ATMS is the analog audio input to the Wireless CPU®. When it is active, it is connected to the radio via the audio processing stages in the Wireless CPU®.

The AFMS is the analog audio output from the Wireless CPU®. When it is active it is connected to the radio via the audio processing stages in the Wireless CPU®.

The AGND is the analog reference signal. ATMS and AFMS are referenced to this signal, which is connected to GND in one place inside the Wireless CPU®.

| Pin | Signal | Description |
|-----|--------|---------------------------------|
| 7 | AFMS | Audio Output From Wireless CPU® |
| 10 | ATMS | Audio Input To Wireless CPU® |
| 9 | AGND | Analog Reference |

Table 19: CM52 Analog Audio Signals

| Signal | Parameter | |
|--------|--|--|
| AFMS | Wireless CPU® audio output | 300 – 3400 Hz |
| | Output Impedance | Rout 100 Ω |
| | Drive capacity into 10 k Ω | 3.77 V _{P-P} max. or 2.5 dBV |
| | External Device audio input impedance | Zin \geq 10 k Ω |
| | Volume control | -81 dB from maximum > - 81 dB (mute) |
| | Sensitivity | 1004 Hz tone at 8kHz deviation generates 900+100 mV _{rms} . |
| ATMS | Sources are preferably AC coupled. | Cout \geq 2.2uF |
| | External Device audio source Output resistance | Rout \leq 1.0 k Ω |
| | Wireless CPU® audio input impedance | Zin \geq 10 k Ω |
| | Levels from external audio source (maximum) | 3.77 V _{P-P} max. or 2.5 dBV |
| | Sensitivity | 1004 Hz tone at 900+100 mV _{rms} generates 8kHz deviation. |

Table 20: Audio Characteristics

Analog Reference (AGND)

- The AGND lead is the analog audio reference ground. It is the return signal for Audio To Mobile Station (ATMS), Audio From Mobile Station (AFMS).
- Electrical characteristics: $I_{max} < 40 \text{ mA (peak)}$
- The AGND is connected to the chassis Ground (GND) in the CM52 Wireless CPU®, and only there. The application should be connected to GND and only use AGND as reference for the audio lines ATMS and AFMS.
- AGND and GND are not to be connected together in the application.

Application Implementation:

BIAS: An analog ground plane should be generated which connects to GND in one point so that high frequency digital current is not floating through the analog ground. Connecting the analog ground in only one point also avoids ground currents from power supplies and other high current circuitry from creating noise in the analog circuitry. The voltage supply for the analog circuitry should connect its ground pin as close as possible to the point where the analog ground connects to GND. The BIAS reference is generated from this supply voltage and analog ground and shall be used as a reference for all analog circuitry in the application. Note that *Analog Ground* and *AGND* are two different signals. *Analog Ground* is the ground plane used by the application. It should be connected to the application's GND in one point preferably at the regulator that generates the analog supply voltage. *AGND* is the analog audio reference received from the phone. This is a signal with the intent to be used together with *ATMS* and *AFMS* as a semi differential interface between the Wireless CPU® and the application.




Figure 14: BIAS Diagram Example

ATMS: An application using the analog audio interface must re-reference the signal from its own internal BIAS to AGND. The figure below shows an example of a microphone implementation.




Figure 15: Microphone Implementation Example

The microphone should preferably be connected to its pre-amplifier differentially which will minimize noise pickup from possible ground current.

AFMS: An application using the analog audio interface must re-reference the AFMS-signal from AGND to its own internal BIAS. The figure shows a differential implementation. C1 is chosen to create the correct HP frequency response. R1 and R2 determine the gain; C2 and R2 determine the LP frequency response.




Figure 16: Differential Implementation Example

2.7 Serial Data Interface

The serial channels are used as asynchronous communication links between the application system and the Wireless CPU®. The following table shows the serial data channels related signals:

| Pin | Signal | Description | Dir |
|-----|--------|--|-----|
| 23 | DCD | Data Carrier Detect This signal is set default high. It goes low indicating that a data call is established (CONNECT received from the remote modem). The signal goes high when the data connection is disconnected. | O |
| 25 | CTS | Clear To Send This signal is initially set high indicating that the Wireless CPU® is not ready to receive data. It is set low after the Wireless CPU® is done performing its startup procedure indicating that it is ready to receive data. | O |
| 26 | DTR | Data Terminal Ready This signal should be set low by the application during a data call. A low to high transition will terminate the data call. | I |
| 27 | TD | Transmit Serial Data To Wireless CPU® (DTMS) The application shall set this signal high at startup. | I |
| 28 | RTS | Request To Send The application shall set this pin low when it is ready to receive data. | I |
| 30 | RD | Receive Serial Data From Wireless CPU® (DFMS) The Wireless CPU® will set this signal high at startup. | O |

Table 21: Serial Data Channels

The common CMOS electrical specifications defined in Section 1.1.1 are valid for all these signals. The standard character format is 1 start bit, 8 data bits, non-parity and 1 stop bit. In all there are 10 bits per character.

Note! The signal levels do not match the standard RS-232 (V.28). If the application signal levels are not compatible with the CMOS levels described in **Table 4: CMOS Output / Input Electrical Characteristics**, then electrical protection level limiters or level conversion hardware will be necessary between the CM52 Wireless CPU® and the application.


2.8 Antenna Interface

The antenna interface of the CM52 consists of a single or dual RF connector for the radio with optional antenna diagnostics and a single RF connector for the optional GPS function.

2.8.1 Antenna Connector

A variety of antenna connectors are available for the CM52 Wireless CPU® including SMA, SMB, and MCX. A standard 5-pin, thru-hole pattern has been selected because of the wide variety of compatible connectors available and also for the maximum mechanical strength.

For automotive applications, a FAKRA-type connector is available which provides a double locking mechanism as well as a keyed, color-coded interface as shown below:



| A Black | B Natural | C Blue | D Violet | E Green | F Brown |
|------------|--------------|------------|-------------|------------|----------------|
| | | | | | |
| G Gray | H Violet | I Beige | K Curry | | Z Waterblue |
| | | | | | |

Figure 17: Color and Keying for various FAKRA connectors

The physical dimensions of a sample SMA connector and mounting hole are shown in the drawing below.




Figure 18: Sample SMA Connector and Mounting Hole

Electrical performance parameters are valid only when the terminating impedance at the output of the antenna connector exhibits a VSWR of less than 2:1 for all phase angles in the frequency band of operation. High VSWR loads at the antenna connector adversely affect current consumption, linearity, and power efficiency of the Wireless CPU® and may degrade operation; however, internal protection circuitry has been added to the design to prevent damage.

The performance of the Wireless CPU® as defined in Section 2.8.2, RF Output Power, is referenced to the antenna connector. The antenna connectors must not negatively affect the performance of the CM52. For this reason, all options are discrete connectors and thus do not include cable assemblies.

The table below lists several suppliers of antenna connectors that are available.

| Description | Vendor / Part # | Additional Information |
|---------------------------|-----------------------|---|
| RF Connectors and cabling | ITT Cannon / Various | http://www.ittcannon.com |
| RF Connectors and cabling | Amphenol RF / Various | http://www.amphenolrf.com |
| RF Connectors and cabling | Hirschmann / Various | http://portal.hirschmann.com |

Table 22: Antenna Connector Suppliers

2.8.2 RF Output Power

The CM52 is able to operate in several modes and different output power level. Applications may require output power levels similar to those in a handheld cellular phone or higher levels commonly required in rural areas.

A CM52 that is a 0.6W variant is an AMPS Power Class III device. A 3W variant will be an AMPS Power Class I device. The following tables show the nominal power provided by the CM52.

| | Mobile Station Power Level (dBm) | | | | | | | |
|------------------------|----------------------------------|------|------|----|----|----|----|---|
| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| Class I, AMPS | 34.8 | 31 | 26.3 | 24 | 20 | 16 | 12 | 8 |
| Class III, AMPS | 26.3 | 26.3 | 26.3 | 24 | 20 | 16 | 12 | 8 |

Table 23: Mobile Station Nominal Analog Power Levels

Note: These numbers represent the Nominal Output Power⁵ in AMPS mode and are referenced to the antenna connector. Analog output power levels are as defined for a Power Class I device in Industry Specification EIA/TIA IS-91.

| | Mobile Station Power Level (dBm) | |
|-------------------------------------|----------------------------------|--------------------|
| | Lower Limit | Upper Limit |
| Class III, CDMA Band Class 0 | 23 dBm (0.2 Watts) | 30 dBm (1.0 Watts) |
| Class II, CDMA Band Class 1 | 23 dBm (0.2 Watts) | 30 dBm (1.0 Watts) |

Table 24: Mobile Station CDMA Maximum Output Power

2.8.3 Carrier Approval

The CM52 has undergone carrier qualification and has been approved referencing the antenna connector. Any application intending to use the CM52 will likely be required to undergo similar testing with the CM52 integrated into the application. For this reason it is strongly recommended that the application is designed to accommodate exposing the antenna connector(s) of the CM52. This will help insure that the qualification of the application with the carrier will be successful.

2.8.4 Antenna Diagnostics

The antenna diagnostics function consists of one antenna detection circuit per RF connector. Each detection circuit can support antenna resistance (RL) values of 1 K Ω to 20 K Ω and 49.9 K Ω . Internal resistance (R) value is either 10 K Ω or 49.9 K Ω , as required by the customer's application. AT commands are provided to query the status, query the limits and set the limits for the status: GOOD, OPEN, or SHORTED. These commands are detailed in the CM52 Software User's Guide and AT Command.

The drawing below is a high level description of the antenna diagnostics circuit.

⁵ PL0 and PL1 require VCC_AUX = 13.8V




Figure 19: Antenna Diagnostic Circuit

The current antenna status is based on a comparison between the voltage measured at the antenna connector and the limits set by the application for OPEN and SHORT.

Because of the tolerances associated with Wireless CPU® power supply, ADC power supply and the ADC itself, there will be a correction factor in the ADC reading as listed below in **Table 25**.

| | Lower Limit | Nominal | Higher Limit |
|-------------------------------------|-------------|---------|--------------|
| ADC Reading Correction (%) | -5 | 4 | 11 |
| ADC Correction (Multiplying Factor) | 0.95 | 1.04 | 1.1 |

Table 25: Range of ADC readings for an external antenna

Example: The multiplying factors shown above are used to establish the ADC limits values for an antenna OPEN, SHORT and nominal conditions of a known antenna resistance value. These limits can be calculated using the formula below:

$$\text{ADC Reading} = 255 * \text{Multiplying Factor} * \text{RL} / (\text{R} + \text{RL})$$

The following example shows calculation using internal resistance (R) = 49.9K and antenna resistance (RL) = 10K.

$$\text{Lower Limit of ADC Reading} = 255 * 0.95 * 10\text{k} / (49.9\text{k} + 10\text{k}) = 41$$

$$\text{Nominal Value of ADC Reading} = 255 * 1.04 * 10\text{k} / (49.9\text{k} + 10\text{k}) = 45$$

$$\text{Upper Limit of ADC Reading} = 255 * 1.1 * 10\text{k} / (49.9\text{k} + 10\text{k}) = 47$$

Note: All ADC values should be rounded up to next integer value.

3 Recommended Interface Circuitry

Abbreviations:

- VCC – Represents the logic supply voltage used by the application.
- VREF_CA– Current amplified reference voltage used for all logic interface circuitry to the CM52.

Component proposals:

- Transistors not showing a base resistor should be interpreted as a BRT (Built in Resistor Transistor) i.e. Toshiba RN1308.
- The inverting buffers should preferably be Schmitt-Triggered, i.e. Toshiba TC7S14 or similar.

3.1 Status Group Recommended Circuitry

The status group contains four signals, one output signal from the application and three input signals to the application.




Figure 20: Status Group Diagram

3.1.1 MODULE_PWR_EN_B

This signal, located on pin 12 in the system connector, enables the main 5V supply in the phone Wireless CPU® so that it powers on. This is an open collector input to the phone Wireless CPU®. Its reference voltage is the VCC_MAIN supply.

3.1.2 VREF

This signal, located on pin 2 in the system connector, provides the application with its logic supply voltage. The application shall current-amplify this signal to use it as a supply (VREF_CA) for its interface circuitry to the Wireless CPU®.

3.1.3 RI

This signal, located on pin 40 in the system connector, provides the application with notification of an incoming call or SMS. Please refer to the CM52 Software User's Guide and AT Command Manual for more details about what events can toggle this signal.

It takes approximately three seconds for the Wireless CPU® to be ready to receive data after it is powered ON by pulling the MODULE_PWR_EN_B signal low. The application should not rely on the ring indicator signal at power up, until the 'Restart' message is received via the RD signal.

3.1.4 HW_SD

This signal, located on pin 15 in the system connector, provides the ability to perform a hardware shutdown of the Wireless CPU®. It is a bi-directional signal that is pulled up inside the phone module.




Figure 21: Pin 15 HW_SD Diagram

The following sequence and diagram illustrate a proper shutdown sequence initiated by the application via the HW_SD pin.

Shut down sequence

1. To request a shutdown of the phone module, the application should provide an active low pulse of 100 ± 25 ms on the HW_SD pin through an open collector output.
2. This pulse is detected by the Wireless CPU®, which confirms the request by enabling its HW_SD output, setting it active low.
3. The application waits for the HW_SD pin to become inactive high.
4. The Wireless CPU® has performed its power down sequence and disables its output resulting in HW_SD becoming inactive high.
5. The application shuts down, disabling MODULE_PWR_EN_B.




Figure 22: Shut Down Sequence Timeline

3.2 Data Group Recommended Circuitry

The data group contains six signals: three output signals from application, two input signals to application, and one I/O signal.




Figure 23: Data Group Diagram

3.2.1 VPPFLASH/DCD

This signal, located on pin 23 in the system connector, can be used by the application to enable flashing of the phone module. To enter flash-mode, the application shall set VPPFLASH_EN active high, then enable the MODULE_PWR_EN_B pin.

3.3 PCM Group Recommended Circuitry

The PCM group contains four signals, three input signals to the application, and one output signal from the application.




Figure 24: PCM Group Diagram

3.4 Analog Audio Group Recommended Circuitry

3.4.1 Creating an analog ground

An analog ground plane should be generated which connects to GND in one point so that high frequency digital current is not floating through the analog ground. Connecting the analog ground in only one point avoids ground currents from power supplies and other high current circuitry from creating noise in the analog circuitry. This common point should be located where the analog supply voltage (VANA) is generated (at filter (A), or regulator (B) depending on implementation).




Figure 25: Creating an analog reference voltage (BIAS)

The BIAS reference should be generated from the analog supply voltage (VANA) and be referenced to the analog ground. This reference shall be used to bias all analog circuitry in the application.




Figure 26: BIAS/VANA Reference

The bias can be tapped directly from the resistor voltage divider, but the amplifier will make the bias more stable and less susceptible to noise.

3.4.2 Analog ground vs. AGND

The AGND signal output from the Wireless CPU® is not a ground. It is an analog reference, connected to the main ground and used by the Wireless CPU® in one place inside the Wireless CPU®. Under any circumstances it should not be used as a ground or connected to application's ground.

AGND must be treated as a signal. Together with ATMS and AFMS it creates a semi differential interface. The analog ground shall be used as ground plane for the analog circuitry of the application. It should not be connected to the AGND signal output from the phone module.

3.4.3 Microphone path

An application using the analog audio interface must re-reference the signal from its own internal BIAS to AGND received from the Wireless CPU®.

The figure below shows an example of a microphone implementation.




Figure 27: Microphone Implementation Example

The microphone should preferably be connected to its pre-amplifier differentially which will minimize noise picked up along the way from the microphone to its amplifier. If the impedance is the same on both microphone lines, and the lines are run in parallel, the same amount of noise is picked up on both lines. This noise is then removed in the differential amplifier stage.

3.4.4 Loudspeaker path

An application using the analog audio interface must re-reference the AFMS-signal from AGND to its own internal BIAS. The figure shows a differential implementation. C1 is chosen to create the correct HP frequency response. R1 and R2 determine the gain, and C2 and R2 determine the LP frequency response.




Figure 28: Loudspeaker Implementation Example

3.5 System connector IO functionality

Note 1: The application IO can be one of the following listed types:

- I Logic input (no pull up or pull down resistors required).
- IOC Logic open-collector input.
- O Logic output (no pull up or pull down resistors required).
- OOC Logic open-collector output.
- I/O Logic I/O.

The pin direction in this table is referenced from the application's point of view.

| Group | Pin No | Name | Application Requirements | App I/O |
|-------|--|---------------|---|---------|
| Data | HW flow control is by default enabled in the phone module. | | | |
| | 27 | TD (DTMS) | Logic output to phone module. The application shall set this output high upon start-up. | O |
| | 30 | RD (DFMS) | Logic input from phone module. | I |
| | 28 | RTS | Logic output to phone module. Pulled down by the phone module (R > 20k). The application shall set this pin low when ready to receive data. | O |
| | 25 | CTS | Logic input from phone module. This signal is initially set high, indicating that the phone module is not ready to receive data. It is set low when the phone module is ready to receive data. | I |
| | 26 | DTR | Logic output to phone module. This signal is pulled up in the phone module (R > 20k). This signal should be set low by the application during a data call. A low to high transition will terminate the data call. This signal is asserted by the application when it wishes to open a communications channel. The phone module then prepares the modem to be connected to the telephone circuit, and, once connected, maintains the connection. When DTR is de-asserted, the phone module is switched to "on-hook" to terminate the connection. | O |
| | 23 | VPPFLASH/DC D | DCD: Logic input from phone module. This signal is set default high. It goes low indicating that a data call is established, (CONNECT) received from remote modem. The signal goes high when data connection is disconnected. Sent from the phone module (DCE) to the application (DTE) to indicate that it has received a basic carrier signal from a (remote) DCE. VPPFLASH: The application shall not apply a voltage to this pin unless they intend to use it as VPPFLASH in which case it becomes a power output. | I/O |
| PCM | 19 | PCMULTD | Logic output to phone module. | O |
| | 20 | PCMDLD | Logic input from phone module. | I |
| | 18 | PCMSYNC | Logic input from phone module. | I |

| Group | Pin No | Name | Application Requirements | App I/O |
|--------------|--------|---------------------|---|----------|
| | 17 | PCMCLK | Logic input from phone module. | I |
| Analog Audio | 9 | AGND | Analog reference. This signal is an analog reference output by the phone module. This signal is connected to GND in one place in the phone module. Under no circumstances shall it be connected to any ground or be used as ground in the application. See 2.4 for more detailed information. | I |
| | 10 | AUX1(ATMS) | Single ended audio output to phone module. | O |
| | 7 | AUX0(AFMS) | Single ended audio input from phone module. | I |
| Status | 12 | MODULE_PWR_EN_B | Logic open collector output that is set low by the application to enable power to the phone module. The pull-up resistor resides in the phone module. | OOC |
| | 2 | VREF | Phone module logic voltage sense input to application. This signal provides the application with the logic system voltage level used by the phone module. | I |
| | 40 | RI | This signal is used to indicate to the application of an incoming voice or data call or SMS. The event is indicated by the signals falling edge and remains low for 100 ms. | I |
| | 24 | RINGER ⁶ | Pulse Modulated logic input from phone module. The application must provide power amplification if the current draw is expected to exceed 1mA. | I |
| | 15 | HW_SD | Bi-directional signal, default set to be an open collector output from the application. | OOC I |
| Unused | 39 | CFMS | No termination. Leave open. | I |
| | 37 | CTMS | No termination. Leave open. | O |
| | 36 | Reserved | No termination. Leave open. | IOC |
| | 35 | Reserved | No termination. Leave open. | IOC |
| | 38 | Reserved | No termination. Leave open. | O |
| | 4 | IO_4_VRTC | No termination. Leave open. | I/O |
| | 3 | IO_3_GPS_FIX | No termination. Leave open. | I/O |
| | 1 | IO_1_TIMEMARK | No termination. Leave open. | I/O |
| Reserved | 13 | OUTPUT1 | No termination. Leave open. | I |
| | 16 | INPUT2 | No termination. Leave open. | O |
| | 11 | INPUT1 | No termination. Leave open. | O |
| | 14 | OUTPUT2 | No termination. Leave open. | I |

Table 26: Pin Direction for General Purpose Signals

⁶ Not currently Implemented in the CM52.

4 Functional Description

The CM52 Wireless CPU® performs a set of telecom services according to TIA/EIA-IS-2000. The functions of the display and keypad, usually used to make calls, are implemented by issuing AT Commands over the serial interface.

See the CM52 Software User's Guide and AT Command Manual for a complete functional description and user scenarios for the CM52.

5 Hints for Integrating the Wireless CPU®

This section, which gives you advice and helpful hints on how to integrate the CM52 with the application, should be taken as a guide.

Note! The circuits on the test board are not shielded. Therefore take proper precautions for avoiding ESD and EMI.

5.1 Precautions

Following is a list of preparations that you should make before beginning the integration work that is described in this section.

- Where to install the Wireless CPU®
- Safety standards
- Network and subscription
- Antenna

5.2 Where to Install the Wireless CPU®

Make sure that the Wireless CPU® is installed in proper environmental conditions such that temperature, humidity, vibration, etc., are not beyond the limits specified for it.

Make sure that the signal strength is sufficient. To improve signal strength, move the antenna to another position. Signal strength may depend on how close the Wireless CPU® is to a radio base station. Degradation in signal strength could be a result of disturbance from another source, for example, an electronic device nearby.

You can verify signal strength by issuing the AT command AT+CSQ. See the CM52 Software User's Guide and AT Command Manual for a description of this and other useful AT commands.

Tip! Before installing the Wireless CPU®, use an ordinary mobile telephone to check a possible location for it. Consider signal strength as well as cable length in determining the location for the Wireless CPU® and antenna. That way you will find out if it is practical to install the Wireless CPU® where you intended.

5.3 Safety Standards

You are responsible for observing your country's safety standards and the relevant wiring rules, where applicable.

5.4 Antenna

5.4.1 Antenna Type

When choosing an antenna for your application you must consider the following requirements:

- The antenna must be designed for the AMPS/CDMA 800 and CDMA 1900 MHz frequency band (dual band) for the CM52.
- The impedance of the antenna and antenna cable must be 50 Ω .
- The VSWR value should be less than 2:1.

5.4.2 Antenna Placement

Always follow the instructions supplied by the antenna manufacturer.

You should place the antenna away from electronic devices or other antennas. The recommended minimum distance between adjacent antennas operating in a similar radio frequency band is at least 50 centimeters.

If the Wireless CPU® is used in the Class I AMPS mode, a separation distance of at least 23 centimeters must be maintained between the radiating antenna and the user or nearby persons. In this mode of operation, the combined connection cable path loss and antenna gain must be no greater than 1 dBi.

5.5 Possible Communication Disturbances

Noise can be caused by electronic devices and radio transmitters.

Free Space **Path-loss** occurs as the strength of the received signal steadily decreases with the distance from the transmitter.

Shadowing is a form of environmental attenuation of radio signals that is caused by hills, buildings, trees or even vehicles. Inside buildings this can cause problems, especially if the walls are thick and reinforced.


Multi-path fading is a sudden decrease or increase in the signal strength. This is the result of interference caused when direct and reflected signals reach the mobile phone simultaneously. Flat surfaces such as buildings, streets, vehicles, etc, can reflect signals.

6 Technical Data

| Mechanical specifications | | | |
|--|---|--------------------------------|--------------------------------|
| Maximum length: | 114 mm | | |
| Maximum width: | 49.50 mm | | |
| Maximum thickness: | 18.97 mm | | |
| Weight: | 68.2 g | | |
| Power supply voltage, normal operation | VCC_MAIN | VCC_AUX | |
| Nominal Voltage: | 5.00 Volts | 13.8 Volts | |
| Voltage range: | 4.50 – 5.50 Volts | 11.0 – 16.5 Volts | |
| Radio specifications | AMPS | CDMA (BC-0) | CDMA (BC-1) |
| Frequency range: | TX: 824 – 849 RX: 869 – 894 | TX: 824 – 849 RX: 869 – 894 | TX: 1850-1910 RX: 1930-1990 |
| Antenna impedance: | 50 Ω | 50 Ω | 50 Ω |
| VSWR (Maximum): | 2:1 | 2:1 | 2:1 |
| Environmental specifications | | | |
| Operating temperature range: | -30°C to +70°C: EIA/TIA/IS-2000 +70°C to +85°C: –3dB Degradation beyond +70°C Spec | | |
| Storage temperature range: | -40 °C to +85 °C | | |
| Relative humidity: | 85% ± 3% at +85 °C | | |
| Stationary Vibration Profile: | | | |
| Mounting Configuration “A” | Frequency (Hz) | PSD (G ² / Hz) | |
| Profile: | 5 – 10 | 0.00998 | |
| | 10 – 200 | 0.029946 | |
| | 200 – 500 | 0.00998 | |
| | Total Grms: | 2.95 | |
| Mounting Configuration “B” | Frequency (Hz) | PSD (G ² / Hz) | |
| Profile: | 10 | 0.02936 | |
| | 170 | 0.00489 | |
| | 200 | 0.00978 | |
| | 350 | 0.00978 | |
| | 400 | 0.01958 | |
| | 750 | 0.000978 | |
| | 950 | 0.00978 | |
| | 2000 | 0.000048 | |
| Total Grms: | 2.86 | | |

| | |
|---|--|
| Non-stationary vibration, including shock | Shock response spectrum I, peak acceleration: - 4 shocks in each axis and direction: 300 m/s ² , 11 ms |
| Bump: | Acceleration 250 m/s ² |
| Free fall transportation: | 1.0 m |
| Rolling pitching transportation: | Angle: 35 degrees, period: 8s |
| Static load: | 10 kPa |
| Low air pressure/high air pressure: | 70 kPa / 106 kPa |

Table 27: Technical Data



wavecom 
Make it wireless

WAVECOM S.A. - 3 esplanade du Foncet - 92442 Issy-les-Moulineaux Cedex - France - Tel: +33(0)1 46 29 08 00 - Fax: +33(0)1 46 29 08 08
Wavecom, Inc. - 430 Davis Drive - Suite 300 - Research Triangle Park, NC 27709 - USA - Tel: +1 919 237 4000 - Fax: +1 919 237 4140
WAVECOM Asia Pacific Ltd. - Unit 201-207, 2nd Floor - Bio-Informatics Centre - No. 2 Science Park West Avenue - Hong Kong Science Park,
Shatin - New Territories, Hong Kong - Tel: +852 2824 0254 - Fax: +852 2824 0255

www.wavecom.com